



INSTALLATION INSTRUCTIONS

Installing Rail:

1. **Mark out bracket positions on wall with centres 620mm.**
 - a. Note: Centres are fixed with no adjustment.
 - b. Check they are straight on wall.
2. Install Rail:
 - a. Remove bracket covers for mounting screw access.
 - b. Sealant is required behind wall brackets for water seal (Not supplied).
 - c. Must be attached to a wooden stud or nog.
 - d. Wall anchors are provided for masonry walls.

Install Wall Elbow And Hand Shower:

1. Install the wall elbow with 15mm parallel thread (Thread not supplied).
 - a. Cut the inlet thread, to a **MIN of 10mm thread** from finished wall.
 - b. Ensure O-ring seal is in place.
 - c. Additional sealant will be required for uneven surfaces.
2. Hand tighten handset to tapered end of hose and ensure seal washer is in place.
3. Connect nut end of hose to water supply and ensure the sealing washer is in place and lightly nip up with a spanner.