

MK10N-SS316

OUTDOOR KITCHEN MIXER



meir®

FEATURES

- Refer to the Meir website for warranty terms & conditions.
- European components and cartridge
- 316 Stainless Steel construction

CARE

- Do not install tapware using any form of acetone silicones.
- Do not apply physical items (such as tools) directly to product.
- Never use house-hold or commercial detergents, citrus based cleaners, or abrasive cleaners.
- Clean using a mild washing soap solution rinsed, and dry with a soft cloth.
- Check for any product defects before installation.
- Refer to the installation manual for correct installation.

CREDENTIALS

- Watermark
- WELS

SPECIFICATIONS

