



Install Hose And Roses:


1. Install hose and ensure sealing washers are in place.
 - a. Nut end to lower outlet on rail and tapered end to the hand set.
2. Install over head rose to rail and hand set to hose and ensure sealing washer is in place.

Diverter Operation:

1. The diverter is a manual operation turn handle either to the left or to the right.

SKYLA AirFlo™ TWIN RAIL SHOWER INSTALLATION INSTRUCTIONS

PRODUCT #	BATCH #
-----------	---------



Please contact country of purchase .

NZ:

Distributed by: Greens Global Limited

PO Box 5055, Hamilton, 3200

22 The Boulevard, Te Rapa, Hamilton 3200

Phone: 07 849 0109, Fax: 07 849 0540

Website: www.greenstapware.com

Email: nzsales@greenstapware.com

Service Hotline: 0800 655 455

Distributed by: Greens Global AUS PTY LTD

36 Naxos Way, Keysborough VIC 3173

Phone: 1800 244 487 Fax: 1800 244 212


Email: aussales@greenstapware.com

Website: www.greenstapware.com

Service Hotline: 1800 244 992

Technical Data

- **Suitable for use with high pressure water supply only.**
Not suitable for gravity-fed water heaters, low and unequal pressure networks.
- Minimum Water pressure: 150kpa.
- Maximum water pressure: 500kpa.
- Pressure over 500kpa will require a limiting valve.
- Installation shall be in accordance with the AS/NZS3500 series of standards.
- Flow rate of 3 star 9 l/m has been rated under the Australian & NZ Water Efficiency Labeling Scheme (WELS).



INSTALLATION INSTRUCTIONS

- **Top Inlet at the diverter.**
- **Diverter size is 35mm x 35mm.**
- **Bottom bracket mount is adjustable with max 800mm Centres.**

Install The 15mm Female Inlet Adaptor:

1. At pipe-out stage install a **brass 15mm male wingback elbow** (not supplied).
 - a. Remove the adaptor from the diverter.
 - i. **NOTE:** Loosen off the grub screw to ensure the O-rings are not cut on the adaptor.
 - b. Note: The female inlet adaptor requires MAX 20mm thread from finished wall.
 - c. **Inlet is at the top.**
 - d. **CHECK: The height required with customer** as there is no height adjustment.
2. Cut the inlet thread to **MAX 20mm** from finished wall.
3. Install adaptor using a spanner or a 10mm Allen key.
 - a. **Back edge of the adaptor to be level with the finished wall as shown.**

Install Mounting Sleeve For Bottom Bracket:

1. Mark out and install mounting block as shown in drawing in line with the inlet to ensure rail will be straight.
 - a. **Note:** For adjusting the bracket height, back off the locking screws inside bracket and retighten.
 - b. Must screw into a wooden stud or nog.
 - c. Wall anchor provided for masonry walls.

Installing Rail:

1. Slide the slide control onto the lower rail.
2. **Install lower rail and top rail** to diverter and **tighten the screws.**
 - a. Lightly grease the O-rings on the diverter.
 - b. **CHECK: The screw is not projecting into the bore on the rail.**
 - i. Loosen off to ensure not to cut the O-rings on the diverter.
 - c. Check alignment of the rail.
3. **Adjust height position of the lower bracket to fit sleeve.**
 - a. Back off the adjusting locking screws inside brackets and **retighten.**
4. Install rail to inlet adaptor and mounting sleeve.
 - a. **Tighten the grub screws** with Allen key to secure rail to mounts.
 - b. Sealant is required behind wall brackets for water seal (not supplied).