




SKYLA AirFlo™ AJUSTABLE RAIL SHOWER INSTALLATION INSTRUCTIONS

PRODUCT #

BATCH #



Please contact country of purchase .

NZ:

Distributed by: Greens Global Limited
PO Box 5055, Hamilton, 3200
22 The Boulevard, Te Rapa, Hamilton 3200
Phone: 07 849 0109, Fax: 07 849 0540
Website: www.greenstapware.com
Email: nzsales@greenstapware.com
Service Hotline: 0800 655 455


Distributed by: Greens Global AUS PTY LTD

36 Naxos Way, Keysborough VIC 3173
Phone: 1800 244 487 Fax: 1800 244 212
Email: aussales@greenstapware.com
Website: www.greenstapware.com
Service Hotline: 1800 244 992

Technical Data:

- Minimum Water pressure: 150kPa
- Maximum Water pressure: 500Pa
- Maximum hot water temperature: 70°C
If the Water temperature exceeds 70°C an approved Tempering Valve must be fitted.
- Installation shall be in accordance with the AS/NZS3500 series of standards.
- Flow rate of 3 star 9 l/m has been rated under the Australian Water Efficiency Labeling Scheme (WELS).

INSTALLATION INSTRUCTIONS



Install Rail:

1. Mark out the mounting sleeve positions.
 - a. Brackets are adjustable to **MAX 830mm centres**.
 - b. Check they are straight on wall.
2. **Install the mounting sleeves** for the top and bottom brackets..
 - a. Must screw into a wooden stud or nog.
 - b. Wall anchor provided for masonry walls.
3. **Adjust height of the brackets to fit sleeves.**
 - a. Back off the adjusting locking screws inside brackets and **retighten**.
4. Install rail to mounting sleeves.
 - a. **Tighten grub screws** with Allen key to secure rail to mounts..
 - b. Sealant is required behind wall brackets for water seal (not supplied).

Install Wall Elbow And Hand Shower:

1. Install wall elbow with 15mm parallel thread (Thread not supplied).
 - a. Ensure O-ring seal is in place.
 - b. Additional sealant maybe required for uneven surfaces.
2. Hand tighten handset to tapered end of hose and ensure seal washer is in place.
3. Connect nut end of hose to water supply and ensure the sealing washer is in place and lightly nip up with a spanner.